

Technical Fact Sheet



Hahnemühle Varnish

Hahnemühle Varnish will professionally add a protective finish to the surface of your canvas inkjet prints. This fast drying varnish comes as a ready-to-use mixture and can easily be applied with a foam roller. Hahnemühle Varnish is water-based. It adds richness to the blacks and color gamut of pigment and ultrachrome inks. It also preserves your colors from fading. Additionally, the varnish will protect your canvases from cracking and guards against fungals caused by environments with high humidity. The varnish leaves nothing but a clear coating after application. Available in 1 litre bottles.



Features

- Increase the lightfastness of prints
- Make the surface water-resistant
- Fast drying varnish
- Comes in a ready-to-use mixture
- Easily applied with a foam roller
- Water-based

Technical Fact Sheet



- Available in three versions: matte, satin and glossy finish

Application Text

Hahnemühle Varnish can be applied easily with a hand roller directly onto the canvas inkjet print. Make sure your prints are completely hard-dried (we recommend allowing the print to dry 24 hours prior to varnishing), as well as dust and lint-free. Before use, thoroughly stir Hahnemühle Varnish for at least 2-3 minutes to achieve an even consistency. Pour a small amount into a roller tray and saturate a foam roller evenly. Using consistent pressure, start rolling in different directions until the entire print is coated. Let Hahnemühle Varnish dry for 2-3 minutes, and then roll the entire area once again – this time without pressure. About 30 minutes later, Hahnemühle Varnish will become dry to the touch. Please note: The drying time depends on the thickness of the layers and other factors such as humidity, air circulation and ambient temperature. We recommend allowing the print to rest overnight

Important Note

All statements, technical information and recommendation are based on tests we believe to be reliable, but the accuracy or completeness thereof is not guaranteed, and the following is made in lieu of all warranties of merchantability and fitness for the purpose: Sellers and manufacturer's only obligation shall be to replace such quantity of the product proved to be defective. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.

Technical Fact Sheet



Technical Data

[Download Hahnemuhle Varnish Safety Data Sheet](#)

[Download Hahnemuhle Varnish technical data](#)

[Download Certificate of Conformity](#)

Technical Fact Sheet



Technical Fact Sheet

